

# MANUAL

Servicebox 817  
INNOVATION



# **Thank you for purchasing this Servicebox to your 817 INN!**


This guide provides the information needed to service and maintain your spreader. A spreader used and serviced properly retain their qualities for a long and profitable life in service, and you get the full advantage of all the features.

Maintenance may only be carried out by qualified personnel.

For more detailed information about spare parts and service instructions, we refer to our manual for the specific spreader.

# Index


Twistlock Assembly	4-9
Wear pads	10-13
Flextrack Chain Assembly	14-15
Summary of all parts included	16
Why use Genuine Parts?	17



# **TWISTLOCK ASSEMBLY**

The twistlock is a genuine ELME part, which is certified and marked with a unique serial number.

The tie-rod is a fixed unit and is not adjustable  
(does not apply for WTP).



### To remove the tie-rod proceed as follows:

- 1 Remove the indicator assy. (item 14) or the Locked / Not locked sensor bracket (item 1), if it is a spreader with WTP or with overheight legs.
- 2 Loosen one of the adjuster bolts at the twistlock cylinder, enough to give some play.
- 3 Loosen and remove the M8 x 80 bolts (item 2) in the top of both twistlocks in the same end beam.\*
- 4 Use two of the M8 x 80 bolts (item 2) as pullers by inserting them in the two threaded holes (item 3) in each of the cranks (item 4) and tighten them alternately until they lift the cranks (item 4) off the top of the twistlock shaft (item 5).
- 5 The tie-rod (item 6) including both cranks (item 4) can now be removed from the endbeam.\*

### To remove the twistlock and sleeve proceed as follows:

- 6 The key (item 7) that locates the crank (item 4) to the twistlock (item 5) is held in place on the twistlock by a roll pin, so that it will remain in place on the twistlock after the crank is removed.

- 7 Support the twistlock (item 5) from below so that it does not drop out. Using a screwdriver prise the collet (item 8) out of the recess in the twistlock (item 5). It is now possible to lower the twistlock out of the end beam. The sleeve (item 9) and lower bearing set (item 10) will in most cases accompany the twist lock as it is removed, this is quite normal.

### **Inspection prior to reassembly**

- 8 After removal of all twistlock parts, remove all grease and dirt from the parts and also from the corner of the end beam. Steam clean or clean with some form of solvent.
- 9 Heck the twistlock (item 5) for wear at the head and also for wear at the bushing surfaces. Inspect the lower (item 10) and upper (item 11) bearing sets for wear and damage, if badly worn or damaged, they should be replaced. The collets (item 8) and the crank (item 4) should be inspected for possible wear or damage and replaced if necessary.

**It should be noted that the state of the collets (item 8) and the recess in the twistlock (item 5) is very important as these parts are carrying the load when a container is lifted.**


### **Replacing / Fitting twistlocks**

- 10 Prepare the sleeve (item 9), place and grease the bushing and fit the four centering springs in the sides of the sleeve.
- 11 Grease the upper bearing set (item 11) and place in position on the greased top surface of the corner plate (in the endbeam) with the convex half uppermost (threaded holes up). Grease the lower bearing set (item 10) and place in position on the greased bottom surface of the corner plate (in the endbeam, the grease will hold it in place).
- 12 Lift the sleeve assembly as assembled in point 10 and position up through the corner plate in the endbeam. Note the direction of the grease nipple! Then place the twistlock in the sleeve, ensuring that both bearings (item 10 and 11) are positioned correctly around the twistlock. Support the assembly with a jack or other means.
- 13 Fit the collets (item 8) with the pointed part upwards.
- 14 Fit the key (item 7) incl. roll pin to the keyway of the twistlock (item 5).

- 15 In order to fit the tie-rod (item 6) it is necessary to mount both cranks (item 4) to the tie-rod before placing it in the end beam.\* Fit the ball joints, O-rings, and plastic washers to the tie-rod ends and then fit the fork of the crank (item 4) over the tie-rod end. Ensure that the countersunk ends of the securing holes in the crank are upper most. Secure the crank to the tie-rod end by fitting the pin (item 12) and then the ring pin and allen screw (item 13).
- 16 In order to simplify assembly of the crank to the twistlock it is advisable to fit two alignment pins to the assy. The pins can be made from two M8 x 75 bolts or allen screws with the heads removed and slightly chamfered.  
These pins should be screwed into the top plate of the upper bearing (item 11) diagonally so that each pin guides one half of the collet (item 8).
- 17 Insert the tie-rod (item 6) into the end beam and then fit the cranks (item 4) onto the alignment pins and ensure that the key and keyway line up. Fit two of the allen securing (item 2) in the remaining two holes and screw in and tighten lightly. Remove the alignment pins and fit the other two securing screws. The securing screws can now be tightened to approx. 25 Nm.
- 18 Activate the twistlocks to the NOT LOCKED position and then adjust the twistlock cylinder adjuster bolts, so that the twistlocks are positioned accurately in the NOT LOCKED position. Then adjust properly, see "Twistlock angle adjustment".
- 19 Grease the complete assembly with a high-pressure grease gun.

In order to test the operation, it is necessary to land the spreader on a container so that the seated pins are activated.


- \* For spreaders with WTP (section 3, 5 and 15 above), the removal/fitting of bolts, tie rods and cranks can be done one by one.



### Seated / Landed signal adjustment


- 1 Check that the SEATED PIN can move up and down freely. The force needed to lift the pin is approx. 10 kg (20 lbs).
- 2 The SEATED signal should switch on with the pin protruding approx. 9 mm below the landing surface of the end beam.
- 3 If adjustment of the proximity switch / sensor is necessary, remove the seated sensor mounting bracket incl. sensor from the top of the seated tower, and adjust the proximity switch / sensor so that the end surface is 7-8 mm above the lower mounting surface of the bracket. This adjustment will result in the seated pin indication being switched on when the underside of the seated pin is approx. 8 to 10 mm lower than the end beams landing surface. This adjustment also ensures that the mechanical and electrical lockout is released so that the twistlocks can be turned.





## Twistlock angle adjustment

- 1 Turn the twistlocks (pos 1) to the fully UNLOCKED position (as shown).
- 2 If the twistlock heads do not line up with the twistlock sleeve, they can be adjusted by loosening the lock nuts (pos 5) for the adjuster bolts (pos 2).
- 3 Turn the twistlocks at each end of the end beam so that they line up with the sleeves, if it is found difficult to line up the twistlocks and sleeves accurately distribute the misalignment equally on both sides of the sleeve. Make sure that the twistlock heads DO NOT protrude outside the theoretical line between the twistlocks. If the twistlocks do protrude outside the previously mentioned line between the twistlocks it can cause jamming in corner castings as the spreader is lifted off the container.
- 4 Run both adjuster bolts (pos 2) up to the piston rod (pos 4) ends of the twistlock cylinder (pos 3) by hand, making sure that neither the twistlocks nor the cylinder are moved. Tighten the lock nut (pos 5a) of the inside adjuster (pos 2a) first.
- 5 Unscrew / back off the outer adjuster bolt (pos 2b) no more than 2 flats of the hexagon head (60°) so that there is only just enough play to allow the tie rod (pos 6) to slide back and forth across the adjuster bolts when the twistlock cylinder (pos 3) is activated. CAUTION if the gap between the twistlock cylinder rod ends is too large the rod ends will hammer against the adjusters and subsequent damage will occur to the piston rod ends.
- 6 Tighten the lock nut (pos 5b) securely while at the same time ensuring that the adjuster bolt (pos 2b) does not move.
- 7 Activate the twistlocks to the LOCKED position and check that the twistlock heads are 90°+/- 10° to the twistlock sleeve.




## WEAR PADS

To eliminate mechanical friction, there are plastic pads between extension beams and main frame. The pads are positioned for support to reduce and also to absorb horizontal and vertical shock loads, they are mounted in several retainers. This design makes inspection and replacement easy.

## Wear pads wear limits

Below pictures and tables show the maximum wear limits for the different wear pads on the spreader. Make sure to regularly inspect the wear pads and to replace them when needed.

The nylon wear pads should be inspected for wear at the same time as their tracks are lubricated. Replacing the wear pads can be done with ordinary hand tools and without removing the beams.




Pos	Qty	Part name	Thickness	Max. wear	Replaced at
1	4	Wear pad, rotator	30 mm	3 mm	27 mm
2	4	Wear pad, rotator	20 mm	3 mm	17 mm
3	12	Wear pad, mainframe side & upper	20 mm	3 mm	17 mm
4	4	Wear pad, mainframe lower	20 mm	3 mm	17 mm
5	4	Wear pad, extension beam, upper	40 mm	3 mm	37 mm
6	2	Wear pad, extension beam, lower	25 mm*	3 mm	22 mm
7	2	Wear pad extension beam, lower	25 mm*	3 mm	22 mm
8	4	Wear pad, extension beam, side	20 mm*	3 mm	17 mm

\*against center of spreader


## Changing wear pads

1. Extend the left extension beam ~1000 mm to make room for service on the right beam. If the spreader has the option hydraulic stops, disassemble the stop cylinder.




2. Use a M6S 20x90 bolt (1) to lift the rear end of the extension beam ~2 mm to make sure the extension beam does not rest on the lower wear pad. There should be a gap left between the upper wear pads and the main frame.

Loosen the 4 bolts (2). In order to replace the side wear pads, remove the inner bolts (3), on each side.




3. Extend the right extension beam ~400 mm. The beam will slide on (1).



## Changing wear pads


4. Now it is possible to remove the upper wear pads by loosening bolts (4) and pull out the wear pad retainer. \*

Remove the side wear pad bolts (5) and pull out the wear pad retainer. \*




5. Remove the lower wear pads (6) by pulling the retainer (7) to the position shown in the below figure. \*

Finish the service by retracting the extension beam and remove the M6S 20x90 bolt (1). Tighten all bolts to recommended tightening torque, according to manual. Reassemble the stop cylinder, if you have the option hydraulic stop.



6. Repeat the procedure for the opposite extension beam.


\*Change wear pads and reassemble in reverse order.




# **FLEXTRACK CHAIN ASSEMBLY**

Included in this service box is a complete assembly of flextrack chain, hydraulic hoses and electrical cable. On the following pages, you will find instructions how to replace the flextrack chain assembly.

## Flex track chain guide



- 1 Cable chain
- 2 Bolt
- 3 Bolt
- 4 Hydraulic hose assy.
- 5 Flex track chain guide



In flex track chain guide

To change flex track chain, loosen and remove the circled bolts, replace the flex track chain and reassemble in reverse order.

## Summary of all parts included in the box:

### Twistlock Assembly

4x	Twistlock kit
4x	Seated pin
4x	Nut
4x	Bracket
4x	Indicator arm
4x	Tie rod
4x	Compression spring
4x	Compression spring

### Wear pads

12x	Wear pad - Mainframe
4x	Wear pad - Mainframe lower
4x	Wear pad - Extension beam lower
4x	Wear pad - Extension beam upper
2x	Wear pad - Extension beam lower
2x	Wear pad - Extension beam lower
4x	Wear pad - Rotator
4x	Wear pad - Rotator
4x	Shims - Rotator
4x	Shims - Rotator

### Flextrack Chain Assembly

2x	Flex track chain
4x	Hydraulic hose assy.
2x	Cable assy.
2x	Cable assy. (work lights)



# Why use Genuine Parts?



## ELME GENUINE PARTS

By using ELME genuine parts, you always get parts you can rely on and true peace of mind. If you are using non-genuine parts, you put weak links into a strong, perfectly designed chain of interactive components. Please note that non-genuine parts are made by factories that have not been approved by ELME and they are often manufactured to be as cheap as possible, using inferior materials, workmanship and by reversed engineering. Non-genuine parts are high risk. Real cost and real risk is measured not in the price, but in the cost of the component in the event of failure. Use of non-genuine parts may lead to higher downtime and lower productivity due to more frequent failures. For correct operation of the spreader, only ELME Genuine Parts and accessories which are approved by ELME should be used. If non-genuine parts are used, the warranty is not valid. By using ELME Genuine Parts and accessories approved by ELME, you will maintain original standard. ELME will disclaim all responsibility if parts from third party are used.

## INSPECTION/MAINTENANCE

Always inspect your spreader before using it. If any kind of damage is detected – which may affect the function of the spreader - this must be corrected before use. If the spreader needs to be repaired, please contact a specialist and see to that only ELME Genuine Parts are used if need of replacement. This is to ensure that the spreader still is reliable. Repairs made by a non-qualified person or use of non-genuine parts may lead to increased risk of personal injuries or damages. Service and maintenance are necessary to keep capacity and efficiency of the spreader for many years.

## MODIFICATION OF THE SPREADER/PRODUCT LIABILITY/WARRANTY

For the avoidance of doubt, ELME is not liable in case of damage due to factors beyond ELME's control or due to a lack of maintenance or the use of non-genuine parts. The spreader should not be modified without consultation with ELME. If so, this means that the spreader is not CE approved and thus ELME has no product liability.

**HEADOFFICE**

ELME Spreader AB  
Älmhult, Sweden  
sales@elme.com  
www.elme.com

**SALES AND SPARE PARTS**

ELME Spreader Trading (Shanghai) Co. Ltd  
Shanghai, China  
sales.cn@elme.cn

**SPARE PARTS**

ELME Americas Inc.  
Martin, TN, United States  
sales.us@elme.com

**ELME**<sup>TM</sup>  
Swedish Spreader Systems