# SERVICEBOX
## 584LB

- Box weight (MPS): 60 kg
- Box weight (PPS): 70 kg
- Dimensions of the box: 80x60x45 cm

### Parts included in the box:

| | |
|---|---|
| **Hook Assembly** | 2x Hook |
| | 2x Pin |
| | 2x Lock washer |
| | 2x Nut |
| | 4x Bushing |
| **Wear pads & Shims** | 10x Wear pad - Endbeam |
| | 24x Wear pad - Mainframe |
| | 6x Wear pad - Carrige |
| | 10x Shims - Mainframe |
| | 8x Shims - Endbeam |
| **Flextrack Chain** | 2x Flex track chain |
| **Additional Items** | 2x Proximity switch |
| | 1x Seal kit - Sideshift cylinder |
| | 1x Seal kit - Extension cylinder |
| | 1x Seal kit - Side clamp cylinder |
| **PPS (option)** | 2x Wear pads (frame) |
| | 2x Shims 1mm (frame) |
| | 2x Shims 2mm (frame) |
| | 2x Wear pads (carriage) |
| | 2x Shims 1mm (carriage) |
| | 2x Shims 2mm (carriage) |
| | 6x Bolts (carriage) |
| | 6x Lock washer (carriage) |
| | 1x Seal kit - Tilt cylinder |
| **Service Manual** | 1x Service manual |

**The idea of ELME Servicebox** is to facilitate service job and preventive maintenance of the spreader by boxing up selected genuine parts. The box includes all the parts we consider needed to be replaced at service.

Purchasing the servicebox directly together with an equipped machine ensures that the ELME spreader continues to hold a high level in terms of its dependability and reliability. Additionally it ensures low downtime and is more economical than buying all the parts individually. Even better is that it keeps the spreader in good condition by regular service checkups!

**ELME Servicebox** is available for many of our spreader models – both empty and laden truck spreaders as well as crane spreaders.

For more information about available models, please visit the ELME Servicebox page at **www.elme.com**

Servicebox 584LB is valid for all standard models delivered from the launch in year 2011.

ELME™
Swedish Spreader Systems

© May 2016 ELME Spreader AB

## ELME GENUINE PARTS - PERFORMANCE, RELIABILITY AND SAFETY

An ELME spreader consists of more than 3,000 parts – all carefully designed and built to provide the highest possible level of **performance**. Elme Genuine Parts, our range of approved spare parts and accessories, are 100 % made for your ELME spreader – with the exact right qualities, dimensions and features – to secure the **reliability** and **safety** of your product. By using ELME genuine parts, you always get parts you can rely on and true peace of mind. If you are using non-genuine parts, you put weak links into a strong, perfectly designed chain of interactive components.

On a number of our spare parts we expand **safety** and traceability with a tooled product labeling, everything to improve the certainty of using genuine parts. Another example of this process is our twistlock certificate. This document ensures the origin and quality of the twistlocks and certifies that the twistlocks are tested.

Every single part of an ELME spreader is built at our plant in Älmhult, Sweden. And that's the way it's been since 1974. All the work is carried out here - from design and product development to manufacturing, assembling and testing. This unique approach lets us have 100 % control over the production and the final quality of our products. It's our way to ensure the **performance**, **reliability** and **safety**.

For more information and Servicebox manual, please visit **www.elme.com.**

**HEAD QUARTER AND PRODUCTION**
**ELME Spreader AB**
Phone +46 476 558 00
Email sales@elme.com
Website www.elme.com

**SALES AND SPARE PARTS**
**ELME Spreader Trading (Shanghai) Co., Ltd**
Phone +86 21 5169 8922
Email sales.cn@elme.com

**SPARE PARTS**
**ELME Americas Inc.**
Phone +1 731 588 02 20
Email sales.us@elme.com

ELME™
Swedish Spreader Systems