## **MODEL 8915**

## FOR LADEN CONTAINER HANDLING WITH MOBILE HARBOR CRANES



#### Standard supply includes:

- One or two pin mounting to fit crane hook
- Four pendular ISO twistlocks
- Lifting eyes near twistlocks
- Hydraulic telescoping system
- Hydraulic center of gravity adjustment
- Hydraulically and mechanically controlled stop pins
- Solenoid valves for all hydraulic functions
- Six hydraulic side flippers
- Electrical and mechanical twistlock protection and indication system
- Electric telescoping protection system
- Lift interrupt signal
- LED indication lights

# Spreader Model 8915 is a telescopic top spreader for handling of laden ISO containers up to 41 tonnes. 8915 is designed for mounting on Mobile Harbour Cranes.

The strong and basic concept offers distinct advantages, such as two parallel telescopic beams, assuring max overlap. Beam sections dimensioned to absorb not only the vertical, but also the very considerable horitzontal forces.

#### TWISTLOCK SYSTEM

The twistlock system is manufactured in a rugged design and is well-proven since many years. 8915 is equipped with hardened, pendular ISO quick exchange twistlocks, hydraulically activated with electrical and mechanical interlocking against faulty locking and unlocking.

#### **TELESCOPING SYSTEM**

Telescoping is powered by one hydraulic cylinder inside each beam.

#### **CENTER OF GRAVITY ADJUSTMENT**

The center of gravity adjustment is executed by one hydraulic cylinder on top of the mainframe.

#### **FLIPPER SYSTEM**

The six side flippers are each powered by two hydraulic cylinders mounted well protected.


#### **HYDRAULIC SYSTEM**


Double electric motor and pump assemblies assure simultaneous telescoping of both beams. The spreader can be operated with one electric motor and pump.


#### CONTROL AND PROTECTION SYSTEM

The control voltage on the spreader is always converted to 24V DC for safety and reliability. Electrical systems monitor the state of the spreader at all times. Indicator lights advise the operator when the spreader is correctly seated, locked or not locked. Each signal is a precondition for the important protection functions of the spreader, such as twistlock activation, telescoping and lift interrupt.












8915



220 μ



Power pack.

Side flippers.

All specifications are subject to change without notice. A list of options enables you to adapt the product more precisely to your needs and further information is available on request.

## HEAD QUARTER AND PRODUCTION ELME Spreader AB

Phone +46 476 558 00 Email sales@elme.com Website www.elme.com

Paint thickness

## SALES AND SPARE PARTS ELME Spreader Trading (Shanghai) Co., Ltd

\* Calculated speed at 20° C

Phone +86 21 5169 8922 Email sales.cn@elme.com

## SPARE PARTS ELME Americas Inc.

Phone +1 731 588 02 20 Email sales.us@elme.com

